

## Radio-ME: Stream High-End audio player

Output mode:

ASIO

System requirements:

2 cores processor (4 core recommended)

installed memory - at least 4 GB (8 GB recommended), of which 2.6 GB must be free

operating system - Windows 7 or newer

Installation.

Installation is not required. Unpack the archive to a suitable location on the disk.

Customization.

At the first launching, a list box of the ASIO driver appears after the initial splash screen. Just click on the desired and active ASIO driver.

In the future, if a selected DAC is active, and its internal settings are unchanged, the setup mode is skipped when you start the player.

To enter the setup mode, when starting the player, click on the initial screen saver or press the "Enter" button.

When you select the ASIO driver, a settings window appears. Here you can set the initial volume level and adjust the configuration of the player.

Control.

To control the player, use the on-screen buttons.

Short keys:

"U" or "+" in the keypad – volume increase

"D" or "-" in the keypad – volume decrease

"S" – stop

"Space" – play / pause

Other.

The ASIO driver buffer is set on the value recommended by the DAC manufacturer or higher.

You can open tracks only with the same sample rate at the same time.

<https://motherearthradio.de/en/index.html>

<https://clearsound.club/#>