

Hi-Res Radio: Stream audio player

Sample rates:

96.0 kHz & 192.0 kHz

Output mode:

ASIO

System requirements:

2 cores processor (4 core recommended)

installed memory - at least 4 GB (8 GB recommended), of which 2.6 GB must be free

operating system - Windows 7 or newer

Installation.

Installation is not required. Unpack the archive to a suitable location on the disk.

Customization.

At the first launching, a list box of the ASIO driver appears after the initial splash screen. Just click on the desired and active ASIO driver.

In the future, if a selected DAC is active, and its internal settings are unchanged, the setup mode is skipped when you start the player.

To enter the setup mode, when starting the player, click on the initial screen saver or press the "Enter" button.

When you select the ASIO driver, a settings window appears. Here you can adjust the configuration of the player and select a color scheme.

Control.

To control the player, use the on-screen buttons.

Short keys:

"S" – stop

"Space" – play / pause

Other.

The ASIO driver buffer is set on the value recommended by the DAC manufacturer or higher.

<https://motherearthradio.de>

<https://clearsound.club>

<https://A-Sky.nl>